





Q

. . .



Installation of equipment

IMPORTANT: It is essential to refer to the installation instructions for information on the size of the safety areas.


Impact area (minimum normative surface)


Free space

Zone d'Inpact Sol souple Inpact Area Wetpour Area de Inpacto Fallraum bei synthetischen Fallschutz



Zone d'Inpact Sol fluent Inpact Area Loose porticle naterial Arenero Fallraun bei Iosen Bodennaterial





	_ ☐ ↓	
1	1,55m	17,5m²
2	1,65m	16m²
3	1,55m	20m²
4	1,65m	18,5m²

